



ALLOTMENTS

STOP VALVE

LEVEL TO existing track

STN 4

STN 5

FP-4

FP-4

AR-4

B-1

B-2

B-3

AL-1

AL-4

AL-2

AL-3

Plot 1

Plot 2

Plot 3

Plot 4

Plot 5

Plot 6

Plot 8

Plot 7

Plot 9

Plot 11

Plot 12

Plot 10

Plot 15

Plot 13

Plot 14

Plot 18

Plot 16

Plot 17

Plot 21

Plot 19

Plot 20

Plot 25

Plot 23

Plot 24

Plot 29

Plot 22

Plot 28

Plot 32

Plot 26

Plot 27

Plot 31

Plot 30

Plot 31

Plot 32

FP-1

FP-2

FP-3

FP-4

FP-5

FP-6

FP-7

FP-8

FP-9

FP-10

FP-11

FP-12

FP-13

FP-14

FP-15

FP-16

FP-17

FP-18

FP-19

FP-20

FP-21

FP-22

FP-23

FP-24

FP-25

FP-26

FP-27

FP-28

FP-29

FP-30

FP-31

FP-32

FP-32